

INSTRUCTIONS FOR INSTALLATION OF AD-125 ADAPTER

1. Remove the screw and black plastic piece that comes in the strobe.
2. Rotate dark grey rubber front piece to one side so that the screwdriver can lay flat.

Remove the screw that comes with the adapter. Use this screw not the one that came with strobe.

3. Insert the AD-125 adapter into the slot, not all the way. Place screw into the hole all the way. Now you can watch that the screw and the hole in the adapter line up. Then take a screwdriver and tighten the screw while slowly pushing the adapter into the slot with the thumb of your left hand. Take your time so you do not cross thread the adapter or the screw.

